

 	<h3>SenseAnywhere AiroSensor Switch Holder</h3> <p>The SenseAnywhere AiroSensor Switch Holder is an accessory which enables you to disable the programmed alarm function of your AiroSensor with a single sliding movement. Just plug in your AiroSensor and slide to the side to either activate or disable the alarm notifications. Ideal for environments with cooling systems that are not operational during nights or weekends.</p> <p>Comes with different labels so you can choose the symbols that match the functionality of your Switch Holder accordingly.</p> <p>Please note: the sliding motion only disables the alarm function. Data logging will continue.</p>
<p>Compatibility:</p>	<p>AiroSensor models 20-20-2x, AiroSensor models 20-20-3x.</p>
<p>Mounting:</p>	<p>The holder is pre fitted with very high bond double sided tape and two stainless steel screws are supplied for mounting in very harsh environments or on rough surfaces. Try to avoid mounting on metal surfaces, reinforced concrete walls, inside metal racks or cabinets for best wireless performance of the sensor.</p>
<p>Material:</p>	<p>PC-ABS, easy to clean surface</p>
<p>Dimensions:</p>	
<p>Height</p>	<p>34mm / 1.34 inch</p>
<p>Width</p>	<p>52mm / 2.04 inch</p>
<p>Depth</p>	<p>25mm / 0.98 inch</p>
<p>Weight:</p>	<p>14g</p>

How does it work?

At SAclient please go to Management > Notification and select the AiroSensor you want to use the Switch Holder with. Change or add a new notification.

At the top of the table you'll see three options to enable the notifications. Select "AUTO". The concerned AiroSensor will now take into account the Switch Holder and its current setting (Alarm notifications ON or OFF).